

An Innovative Product  
Developed By:



AEI PROTECT-ON  
SYSTEMS LIMITED

<http://www.apo-hk.com>



SINCE 1979

ADVANCED ELECTRONICS INDUSTRY

MANUAL NUMBER: HA-268-I Rev. 0  
Ver. 01/08

**8-ZONE ALARM CONTROL PANEL  
WITH AUTO-DIALER AND COMMUNICATOR**

**HA-268**

**INSTALLATION MANUAL**

**FOR HOME AND OFFICE PROTECTIONS**



SINCE 1979

**CE0678**

## TABLE OF CONTENTS

<b>PREFACE</b> .....	4
<b>INTRODUCTION</b> .....	4
Alarm Reporting Chart .....	4
<b>THE SYSTEM CONTROL CONSOLE AND ITS INDICATORS</b> .....	5
The Sound Indicators .....	5
The LED Light Indicators .....	6
<b>TERMINAL DEFINITIONS AND DESCRIPTIONS</b> .....	7
The Terminals On Main Printed Circuit Board .....	7
Utilize Remote Key Switch For Arm-Disarm Controls .....	9
The Terminals On Master and Auxiliary Control Consoles .....	11
Connection of Power Transformer .....	11
<b>FACTORY SETTINGS</b> .....	12
The Purpose Of The Default Programming Setup .....	12
The Default Data Chart .....	12
<b>PROGRAMMING THE PANEL</b> .....	13
How To Enter Programming Mode .....	13
Use the factory set master code .....	13
Use your own master code .....	13
Use the DAP jumper Directly Access to Programming mode .....	14
Start The Programming .....	14
Recording the master code .....	14
Recording the client code .....	15
Recording the user codes .....	15
The duress code (A Software Zone) .....	16
Using the duress code .....	16
Configuration of the protection zones .....	17
Setting the exit delay time .....	18
Setting the entry delays .....	18
Setting the siren duration .....	18
The key entry pacifier tones .....	19
Forced to arm or arm prohibited mode .....	19
Setting the handover function .....	20
Telephone numbers for communicator .....	20
Telephone numbers for auto-dialer .....	21
Putting pause to a telephone number .....	21
Why pause is necessary .....	22
When pause is required .....	22
Dialing to an auto-pager station from the auto-dialer .....	22
Sending an alarm report to your auto-pager from communicator .....	23
Sending voice message/alarm report via an PABX system .....	23
Function keys corresponding to DTMF symbols & instruction for sending report .....	24
Dialing attempts for communicator .....	24

## TABLE OF CONTENTS

Dialing attempts for auto-dialer .....	24
Message repeats .....	25
Backup or non-backup reporting .....	25
Listen-in enable and duration .....	26
Arm-disarm report .....	27
Selection of dialing combination .....	27
Selection of dialing mode for calling the telephone central office .....	28
Numbering beep tones for control panel identification .....	28
Number of rings to pick-up telephone line .....	29
Periodic report .....	30
Power-up delay .....	30
Periodic battery test .....	31
Dial tone and telephone line fault detects .....	31
Set the habitual bypassed zones in memory for HOME mode .....	32
Recording the voice message .....	32
Setting the system with default values .....	33
Exit The Programming Mode .....	33
<b>PROGRAMMING SUMMARY CHART</b> .....	34
<b>COMMUNICATOR'S ALARM-STATUS REPORT FORMAT</b> .....	38
Description Of The Report Parameters .....	39
Client ID .....	39
User number .....	39
Zone status .....	39
System status .....	39
Check sum .....	40
The Acknowledgement Signal For Communicator .....	40
Interpreting The Report - Examples .....	40
<b>ALARM--SYSTEM STATUS--TESTING EVENTS REPORTING MEDIA SUMMARY CHART</b> ..	41
<b>ACCESS THE SYSTEM REMOTELY</b> .....	42
The Meaning Of The Answering Beeps .....	42
The Command Codes For Remote Access Control .....	42
Remote Arm-Disarm The System By Telephone .....	43
Call For A Status Report .....	44
<b>THE AC AND BATTERY POWER</b> .....	45
AC Power Failure And Restoration .....	45
Dynamic Battery Testing .....	45
Battery Low Indications And Auto Reset .....	45
Power Up Delay .....	46
The Back-up Battery .....	46
<b>GENERAL SPECIFICATION</b> .....	46
<b>OPENING THE CABINET FOR SERVICE</b> .....	47

## PREFACE

This installation manual is one of the two manuals for the HA-268 alarm control panel. This manual explains all the aspects in programming, connection terminal functions and the system features. All system parameters and options are described in detail.

To get most from the alarm system, we suggest that you take time to read through this manual and familiarize yourself with the system and its many outstanding features.

The operational procedures of the alarm system are described in the **Operator's Manual**.


## INTRODUCTION

HA-268 is a smart alarm control panel with 8 hardware protection zones and 2 software zones for panic and duress alarms, which is designed for home and office protections using the latest security concepts. The system is built-in with auto-dialer and communicator in one unit. When alarm occurs, it gives local alarm warnings as like the traditional alarm systems, and it also sends out voice message to the pre-set telephones, numeric message to the auto-pagers and an alarm report to a proprietary monitor station which is equipped with your own or the AEI's Alarm-Monitor software, MS-980.

HA-268 control panel is compatible with all the public telephone systems.

## ALARM REPORTING CHART

OFFICE, HOME, FACTORY,  
WAREHOUSE, SHOP, ETC.



### NOTE:

The Alarm Monitor software, MS-980 is not supplied. It is required to purchase separately.

## THE SYSTEM CONTROL CONSOLE AND ITS INDICATORS



MATER CONTROL CONSOLE  
(Non-weatherproof due to MIC hole)



AUXILIARY CONTROL CONSOLE  
(Weatherproof)

## THE SOUND INDICATORS


SOUND	MEANING
1 short beep	<ul style="list-style-type: none"> <li>Successful key entry, a pacifier tone</li> </ul>
2 short beeps	<ul style="list-style-type: none"> <li>Successful code entry for the specific function</li> </ul>
5 short beeps	<ul style="list-style-type: none"> <li>Unsuccessful code entry for the specific function</li> <li>Wrong code number entered</li> <li>Unauthorized command attempted</li> <li>Code entry time expired, 10 seconds maximum per digit is allowed</li> </ul>
1 long beep	<ul style="list-style-type: none"> <li>Exit delay expired, system is armed</li> </ul>
1 short beep/30 seconds	<ul style="list-style-type: none"> <li>AC power failure</li> <li>Battery low</li> </ul>
Continuous beeping at 0.5 second interval	<ul style="list-style-type: none"> <li>Exit delay time</li> <li>Entry delay time</li> <li>The DAP jumper is ON</li> </ul>
Continuous 5 short beeps/5 seconds interval	<ul style="list-style-type: none"> <li>The telephone line is faulty after line fault testing</li> </ul>
2 beeps + 5 beeps	<ul style="list-style-type: none"> <li>System can not be armed instantly due to <b>ARM PROHIBITED</b></li> <li>Duress code is entered but the communicator is not working</li> </ul>

## THE LED LIGHT INDICATORS

INDICATORS	ON	OFF	FLASHING
<b>ZONES (8 LEDs)</b>	<ul style="list-style-type: none"> <li>Zone unsealed (<i>faulted</i>) Please check the zone connections</li> </ul>	<ul style="list-style-type: none"> <li>Zone sealed (<i>Normal</i>)</li> </ul>	<p><b>FLASHING FAST</b></p> <ul style="list-style-type: none"> <li>Zone is or was in alarm</li> </ul> <p><b>FLASHING FAST WITH STOPPING INTERVAL</b></p> <ul style="list-style-type: none"> <li>Zone is in alarm memory, system is disarmed</li> </ul> <p><b>FLASHING SLOW</b></p> <ul style="list-style-type: none"> <li>Zone is isolated</li> </ul>
<b>EXIT/ARMED</b>	<ul style="list-style-type: none"> <li>Alarm armed</li> </ul>	<ul style="list-style-type: none"> <li>Alarm disarmed</li> </ul>	<ul style="list-style-type: none"> <li>In exit delay period</li> </ul>
<b>AC POWER</b>	<ul style="list-style-type: none"> <li>AC Power is being supplied</li> </ul>		<ul style="list-style-type: none"> <li>AC power failure, system is using battery</li> <li>Flashing starts 20-30 seconds after AC power failure</li> </ul> <p><b>FLASHING ALTERNATIVELY WITH THE "BATTERY" INDICATOR</b></p> <ul style="list-style-type: none"> <li>System is in power-up delay period</li> </ul>
<b>BATTERY</b>	<ul style="list-style-type: none"> <li>Battery faulted</li> </ul>	<ul style="list-style-type: none"> <li>Battery normal</li> </ul>	<ul style="list-style-type: none"> <li>The battery is under testing</li> </ul> <p><b>FLASHING ALTERNATIVELY WITH THE "AC POWER" INDICATOR</b></p> <ul style="list-style-type: none"> <li>System is in power-up delay period</li> </ul>
<b>PROGRAM</b>	<ul style="list-style-type: none"> <li>System in program mode</li> </ul>	<ul style="list-style-type: none"> <li>Normal state</li> </ul>	
<b>ARM PROHIBITED</b>	<ul style="list-style-type: none"> <li>System in arm prohibited mode, indicator is ON during exit delay period</li> </ul>	<ul style="list-style-type: none"> <li>System is armed after exit delay expired</li> <li>System in forced to arm mode</li> </ul>	<ul style="list-style-type: none"> <li>The system can not be armed after exit delay expired due to faulty zone(s) existing, see zone indicator for the faulty zone(s)</li> </ul>
<b>DIALING</b>	<ul style="list-style-type: none"> <li>Dialing in DTMF format</li> </ul>	<ul style="list-style-type: none"> <li>No dialing is in progress</li> <li>Dialing for duress after the duress code is entered</li> </ul>	<ul style="list-style-type: none"> <li>Dialing in pulse format</li> </ul> <p><b>FLASHING TWICE</b></p> <ul style="list-style-type: none"> <li>The system is in telephone line fault testing</li> </ul>
<b>RECORDING</b>	<ul style="list-style-type: none"> <li>Voice recording is in progress</li> </ul>	<ul style="list-style-type: none"> <li>No recording, or the recording time is expired</li> </ul>	

## TERMINAL DEFINITIONS AND DESCRIPTIONS

## THE TERMINALS ON MAIN PRINTED CIRCUIT BOARD



- 1, 2: AC Power is supplied from a 16.5V AC, 1.5Amp minimum transformer at 50 or 60Hz. The primary side of the transformer must be connected to an unswitched receptacle.

**NOTE:** The transformer to be used in this product must be complied in the EN61558 standard (AEI Model: AP-980).

- 3: This terminal provides an unswitched +12V output power referring to the common ground. It gives output power all the time no matter the system is armed or disarmed. Suitable for those devices require uninterrupted power supply. Such as smoke detectors, control keypads etc. This terminal is equipped with a 750mA resettable fuse.

- 4: This terminal provides a switched +12V output power referring to the common ground when the system is turned ON. The output voltage is OFF when the system is disarmed. It is prepared for devices that require switched power for resetting. Typical devices are glass-break detectors and some of the smoke detectors that require power OFF to reset. This terminal is equipped with a 750mA resettable fuse.

**NOTE:** Terminals 3 and 4 share the same power bus. Combined power for these outputs should not exceed 750mA.

- 5: Common Ground (-).

- 6: This terminal provides a continuous +12V output power at normal condition of no alarm occurred. Mostly suitable for the connection of Satellite Siren/Strobe Light. The +12V output is switched OFF at alarm condition. The output is equipped with a 2.5A resettable fuse.

**REMARK:** A Satellite Siren-Strobe Light unit is a self-contained device with built-in backup battery which is charged by the hold-off voltage from the control panel at normal condition. At which, the siren and strobe light are OFF.

At alarm condition, the hold-off voltage from the control panel is cut. The siren and strobe light at the unit start to work. They are supplied by the backup battery. The siren will stop when the pre-set time expires, and that the strobe light will work until the hold-off voltage resumes.

A Satellite Siren-Strobe Light is self-protected and tamper-proof. It gives alarm instantly if the connection wire between the unit and the alarm control panel is cut.

- 7: This terminal provides a continuous +12V output power at and after alarm condition until the system is disarmed or reset by the user code. It is mostly suitable for providing power for the stand alone strobe light or those devices require continuous operation at alarm condition after the siren timer is reset. The output is equipped with a 2.5A resettable fuse.

- 8: This terminal provides +12V output power at alarm condition with the time period according to the setting of the alarm timer. It is suitable for energizing electronic siren or alarm bell. The output is equipped with a 2.5A resettable fuse.

- 9: This terminal is prepared for connecting the arm-disarm control keyswitch (AEI Model: RKS-2M) or the wireless remote controller (AEI Model: RPS-302M). It accepts Normally Open (N.O.) momentary switches and is +12V triggered. Maximum 5 switches can be connected in parallel.

## UTILIZE THE REMOTE KEY SWITCH FOR SYSTEM ARM-DISARM CONTROLS

ARM THE SYSTEM		
KEY SWITCH CONTACT	STATUS	RESULTS
1st Touch	● Away mode arming	<ul style="list-style-type: none"> <li>● Exit delay starts</li> <li>● Exit beep sounds if it is enabled</li> <li>● System will be armed after exit delay expired</li> </ul>
2nd Touch	● Home mode arming	<ul style="list-style-type: none"> <li>● The 2nd touch must be made within the exit delay period</li> <li>● Exit beep sounds continuously until the end of the exit delay</li> <li>● System will be armed after exit delay expired</li> </ul>
DISARM THE SYSTEM		
1st Touch	● System disarmed	<ul style="list-style-type: none"> <li>● The system is disarmed and reset if there was no alarm occurred. It is ready for re-arming</li> <li>● The system is disarmed but with alarm memory if there was alarm occurred, 2nd touch is required</li> </ul>
2nd Touch	<ul style="list-style-type: none"> <li>● Alarm memory is cleared</li> <li>● System keeps in disarmed mode</li> </ul>	<ul style="list-style-type: none"> <li>● The alarm memory LEDs on the control console are off</li> <li>● The system is ready for re-arming</li> </ul>

- 10,11,12,13: This group of terminals are the connection points for the system control console(s). All consoles should be connected in a parallel configuration back to these terminals and maximum 4 consoles can be allowed.

10: +12V power common point, equipped with a 750mA resettable fuse

11: Common ground (-)


12: Clock wire

13: Data wire

- 14: Microphone signal input point. Connect the microphone wire from the Master Control Console to this terminal.

- 15,16,17,18, 19,20,21,22, 23,24,25,26: These terminals are protection zones 1 to 8 and their common grounding terminals. The zones are E.O.L. (End of Line) monitored by a 2.2K Ohm resistor.

All normally closed (N.C.) contacts are to be wired in series with the E.O.L. resistor, where all normally open (N.O.) contacts are to be wired in parallel with the E.O.L. resistor. The function of the zones and their response times are programmable via the system programming options.





A protection zone with E.O.L resistor, either an open or a short will be reported as an alarm if the zone is in armed state.

15: Zone 1, 17: Zone 2, 18: Zone 3, 20: Zone 4,  
21: Zone 5, 23: Zone 6, 24: Zone 7, 26: Zone 8,  
16, 19, 22, 25: Common ground (-)

**IMPORTANT NOTE: TAMPER SWITCH (N.C.)**

The cabinet's tamper switch is pre-wired to zone 8 internally. Suggest always keep zone 8 programmed as a 24-hour protection zone.

**27,28:** These two terminals are prepared for the connection of the house telephone set which is connected to the telephone line in normal condition. The house telephone set will be automatically disconnected from the telephone line whenever the communicator or the auto-dialer goes into action.

**29:** This is the earth point of the system. This terminal should be connected to a nearest solid electrical earth point such as a cold water pipe or earth stake in order for it to provide protection against possible lightning interference. Use 14 gauge wire or larger for this connection. **Failure to earth the unit compromises safety!**

**30,31:** These two terminals are prepared for connecting the incoming telephone line. The system connects the house telephone set to the telephone line in normal condition, and it picks up the line for the communicator or the auto-dialer whenever it goes into action.

**BATTERY:** The (+) RED wire connects to the positive terminal of the battery and the (-) BLACK wire connects to the negative terminal of the battery. The battery should be a 12V sealed lead acid rechargeable type with a capacity of 6.5AH. The battery is protected by a 3A resettable fuse, and it is charged by a current limiting regulated voltage source in the system.

**DAP JUMPER:** DAP stands for Direct Access to Programming. This jumper is prepared for setting the system into programming mode in case that the personal master code is forgotten. Please see page 14 for the procedure details.


**D.T. JUMPER:** Two Dial Tones are commonly used at today's telephone central office, the continuous dial tone and the cadenced tone comprising the repeated sequence of ON and OFF of the tone.

It is important to make the correct setting in your system to match the dial tone used at the telephone central office in your city. The D.T. JUMPER (Dial Tone Selection Jumper) can be found at the right hand side of the main circuit board. Put jumper on:

- 1) **CONT.** for continuous dial tone (Factory put jumper on 1)
- 2) **CAD.** for cadenced dial tone

Incorrect setting of the D.T. JUMPER may cause malfunction to the "Dial Tone & Line Fault Detects", or the "Ring Detect To Pickup Telephone Line On Remote Access" that you programmed.

**THE TERMINALS ON THE MASTER AND AUXILIARY CONTROL CONSOLES**



**(+) 12V:** +12V power input terminal, connect it to terminal 10.

**(-) 12V:** The common grounding point, connect it to terminal 11.

**CLOCK:** The clock line of the system, connect it to terminal 12.

**DATA:** The data line of the system, connect it to terminal 13.

**TAMPER N.C.:** These are the connection terminals of the tamper switch in the control console. Connection of it is optional. If connection is required, connect it to a normally closed (N.C.) 24-hour zone and zone 8 is suggested.

**NOTE:** The maximum wire length for connecting any control console is 500 feet (152m) of 22 AWG (0.643mm) copper wire. The system is capable to handle maximum 4 control consoles.

**MIC:** The output signal of the built-in microphone on Master Control Console. Connect it to terminal 14.


**REMARK:**

- (1) The MIC output is available on the Master Control Console only.
- (2) Auxiliary Control Console can be purchased separately if required.
- (3) Maximum 4 control consoles (1 Master + 3 Auxiliary) can be connected in parallel to the system.

**CONNECTION OF POWER TRANSFORMER**

AP-980 power transformer is recommended for 220-240V AC operation, which is 16.5VAC output, 3 Amp maximum rating. Power transformer is purchased separately.

- Connect the 16.5VAC output voltage to terminals 1 and 2 on the board.
- Wiring to the AC transformer must not exceed 100 feet using 16 gauge wire. The voltage reading between terminals 1 and 2 of the control must not fall below 16.5VAC. Always put the power transformer closed to the control.
- Do not plug the transformer into AC outlet until all wiring connections to the control are complete. As a safety precaution, always power down the control when making such connection.
- The power transformer can be fixed on wall with screw.



## FACTORY SETTINGS

The system has been programmed with the following default values before exit factory. The default values can be changed with the programming option values if they are not suitable for your application.

Please refer to **Programming the Panel** for details if re-programming is required.

### THE PURPOSE OF THE DEFAULT PROGRAMMING SETUP

The default programming setup of the alarm system allows the owner to operate the system as a local alarm panel without programming except the **Master Code** and the **User Code**.

### THE DEFAULT DATA CHART

PROGRAMMING LOCATION	PARAMETERS	DEFAULT VALUES	PROGRAM DATA
01	Master code	1234 (This is not a default value under the default programming operation. It is a value that factory put in the system before exit factory) .....	Code=1234
10	Client code	0000.....	0000
11-18	User code 1-8	Nil .....	nil
21	Zone 1	Multiple trigger, Entry delay 1, 500mS response ..	Code1=1,Code2=1,Code3=2
22	Zone 2	Multiple trigger, Entry delay 1, 500mS response ..	Code1=1,Code2=1,Code3=2
23	Zone 3	Multiple trigger, Instant, 500mS response .....	Code1=1,Code2=0,Code3=2
24	Zone 4	Multiple trigger, Instant, 500mS response .....	Code1=1,Code2=0,Code3=2
25	Zone 5	Multiple trigger, Instant, 500mS response .....	Code1=1,Code2=0,Code3=2
26	Zone 6	Multiple trigger, Instant, 500mS response .....	Code1=1,Code2=0,Code3=2
27	Zone 7	Multiple trigger, 24-Hr Instant, 500mS response ..	Code1=1,Code2=3,Code3=2
28	Zone 8	Multiple trigger, 24-Hr Instant, 500mS response ..	Code1=1,Code2=3,Code3=2
30	Exit delay	Exit beep enabled, 60 seconds .....	Code=1, duration=60
31	Entry delay 1	Entry beep enabled, 30 seconds .....	Code=1, duration=30
32	Entry delay 2	Enter beep enabled, 60 seconds .....	Code=1, duration=60
33	Siren duration	Arm-disarm ring-back disabled,300 seconds .....	Code=0, duration=300
34	Pacifier tones	Key entry pacifier tones enabled .....	Code=2
40	Arming type	Forced to arm .....	Code=0
41	Alarm handover	Disabled .....	Code=0
50-51	Telephone number for communicator	Nil.....	nil
60-63	Telephone number for auto-dialer	Nil.....	nil
70	Dialing attempts for communicator	4.....	Code=4
71	Dialing attempts for auto-dialer	4.....	Code=4
72	Recorded message repeats for auto-dialer	4.....	Code=4
73	Dialing backup/non-backup selection	Non-backup .....	Code=0
74	Listen-in period	60 seconds.....	Duration=60
76	Arm-disarm report	Disable .....	Code=0
80	Dialing combination	Communicator OFF, Voice dialer ON .....	Code=2
81	Dialing mode	Tone (DTMF) .....	Code=0
82	Alarm control panel numbering	Disabled .....	Code=0
83	Number of rings to pick-up telephone line	16 .....	Code=16
84	Periodic report	Disabled.....	Code=0
HOME	Bypassed zones in memory	Nil.....	nil
RECORD	Voice message recorded	Nil.....	nil
85	Power up delay	Disabled.....	Code=0
86	Periodic battery test	Disabled.....	Code=0
87	Dial-tone and line fault detects	Enabled .....	Code=1

## PROGRAMMING THE PANEL

You can program the panel from the system control console. Firstly, you are required to make the system in programming mode, then key in the two digit *Programming Location* or the *address*, followed immediately by the desired programming values (*program data*), then press the [#] key to store the data. The console will beep twice to confirm the data is successfully stored, and that 5 beeps will be generated for unsuccessful data entry. If you are not sure that the correct programming values have been entered, program the programming location again. After programming is finished, press the [\*] key twice to leave programming mode.

The maximum allowable time for each digit entry is 10 seconds.

### ATTENTION:

To prevent triggering of the tamper switch, please make sure that the cabinet is firmly closed before applying power to the system. Also, do not install battery before the system is programmed. Otherwise, the tamper switch will be triggered instantly to give alarm before the door is closed, and there will be no user code available for turning off the alarm.

## HOW TO ENTER PROGRAMMING MODE

### 1. USE THE FACTORY SET MASTER CODE

For the owner's convenience in programming at the first time, the factory has put a Master Code 1234 into the system. The owner can use this code for the system to enter to programming mode. To compromise security, in all cases, the owner should program a personal Master Code to invalidate the factory set Master Code.

FACTORY SET MASTER CODE	VALIDATION
1 2 3 4	* *

- The console will beep twice to confirm that the system is in programming mode.
- The **PROGRAM** LED is ON.

### 2. USE YOUR OWN MASTER CODE

In the case that the factory set Master Code was replaced by your own Master Code, you have to use your personal Master Code to enter to programming mode.

MASTER CODE	VALIDATION
MASTER CODE	* *

- The console will beep twice to confirm that the system is in programming mode.
- The **PROGRAM** LED is ON.

### 3. USE THE DAP JUMPER DIRECTLY ACCESS TO PROGRAMMING MODE

If the factory set master code was deleted and the personal master code is forgotten. Use the DAP jumper to override the forgotten code permitting direct entry into programming mode. The DAP jumper can be found on the master circuit board. The owner is required to apply the following procedures precisely when use the DAP jumper:



- i ) Disconnect the power supply including both AC power and the back-up battery.
- ii ) Displace the DAP jumper from OFF to ON position.
- iii ) Reconnect the power supply, the console will beep continuously.
- iv ) Put the DAP jumper back to OFF position, the beep stops and the **PROGRAM** LED is ON.
- v ) The system is in programming mode now, and it is ready to receive new data.
- vi ) The DAP jumper is normally left on OFF position after programming.

### START THE PROGRAMMING

After the system is set in programming mode, you can start to program the system with your desired programming values. You can make the programming for all the program options continuously or just select those options that you require. It is not necessary to make the programming in order sequence; you can jump to any **Programming Location** that is available in the system.

### RECORDING THE MASTER CODE

(Location: 01)

LOCATION	MASTER CODE	VALIDATION
01	2 TO 5 DIGITS	#

- The master code can be 2 digits minimum to 5 digits maximum.
- When the new personal master code is entered, the factory set master code or the code that was programmed will be erased.

### RECORDING THE CLIENT CODE

(Location: 10)

LOCATION	CLIENT CODE	VALIDATION
10	4 DIGITS	#

- The client code is the client's identification number, it must be programmed with 4 digits. The system will reject the code if it is not exact 4 digits.
- The client code is not necessary if the alarm system is not linked to the monitor station.
- When a new code is entered, the old code will be replaced.
- The default value of the client code is 0000.

### RECORDING THE USER CODES

(Locations: 11-18)

LOCATIONS	USER CODES	VALIDATION
11	2 TO 5 DIGITS	#

- LOCATIONS:**

11=User Code 1 (Also the code for remote control)	15=User Code 5
12=User Code 2	16=User Code 6
13=User Code 3	17=User Code 7
14=User Code 4	18=User Code 8
- The user codes can be 2 digits minimum to 5 digits maximum.
- User code 1 is also the authorization code of the system to accept remote arm-disarm control from any DTMF telephone.
- Usually only one user code is required to arm-disarm the system.
- Programming of the user codes 2 to 8 is optional, unless more than one users are required to operate the alarm system.
- When a new code is entered into the location, the old code will be replaced.
- To invalid a code, just key-in the specific location number followed immediately by the [#] key without program data.



## THE DURESS CODE (A SOFTWARE ZONE)

The duress code does not need to be programmed. The system determines it automatically by increasing the first digit of the user code(s) of **TWO** units. All 8 user codes can accept the entry for duress function.

**Example:** User Code 1328, Duress Code 3328  
 or User Code 8312, Duress Code 0312  
 or User Code 0856, Duress Code 2856

### Important Notes:

- When program the system with more than one user codes, it is important that the user codes will not fall into the duress code of other user codes.
- For example, if user code 1 is 1328, it is not allowed to make other user code to 3328, as 3328 is the duress code of user code 1.
- The duress function only activates the communicator and the telephone dialer without activating of the local alarm outputs (*the siren & strobe*). Make sure that at least either the dialer or the communicator is enabled for reporting alarms. Otherwise, the duress code can give no function.

### USING THE DURESS CODE

The following is the description of the duress code operation. It is not a programming procedure.

- To command the duress function, enter the duress code and validate via the [#] key.

DURESS CODE


#

- The duress code is valid at anytime no matter the system is armed or disarmed. The system exhibits the following behaviours when the duress code is entered.
- System behaviours:

BEFORE KEYING - IN THE DURESS CODE	AFTER KEYING - IN THE DURESS CODE
System was armed	System is disarmed and starts dialing for reporting alarm
System was disarmed	System is still disarmed and starts dialing for reporting alarm.

## CONFIGURATION OF THE PROTECTION ZONES

(Location: 21-28)



### CODE 1--TRIGGERING MODE

- 0---SINGLE TRIGGER:** The zone can only give alarm once. It does not accept 2nd triggering to prevent noise pollution. The zone will be refreshed when the system is reset.
- 1---MULTIPLE TRIGGER: (DEFAULT FOR ALL 8 ZONES)**  
 The zone can be re-triggered after alarm was occurred if the system is still armed.

### CODE 2--LOOP RESPONSE MODE

- 0---INSTANT:** The zone gives no entry delay and triggers the alarm instantly.
- 1---ENTRY DELAY 1:** The zone gives entry delay according to the time setting on the entry delay timer 1.
- 2---ENTRY DELAY 2:** The zone gives entry delay according to the time setting on the entry delay timer 2.

**REMARK :** The purpose of entry delay 1 and entry delay 2 is to provide operation convenience for the owner to reach the panel from different entrances of the house to disarm the system.

**For example:** entering the house from the garage usually requires more time than from the main door. With the help of 2 entry delays, the owner can set different entry delay times for the two entrances.

- 3---24-HOUR INSTANT:** The zone is always in standby mode, no matter the system is armed or disarmed. It gives instant alarm whenever it is triggered.


- 4---24-HOUR SILENT PANIC:** The zone is always in standby mode, no matter the system is armed or disarmed. It activates the communicator and telephone dialer but not the local alarm output (*no siren and strobe light*) whenever it is triggered. Make sure that either the dialer or the communicator is enabled for alarm reporting, otherwise, the zone gives no function and the zone LED will be ON showing that it is a faulty zone.

### CODE 3--LOOP RESPONSE TIME

Loop response time is the time required to trigger a protection Zone.

- 0 -- 25 mS                      2 -- 500 mS (DEFAULT FOR ALL 8 ZONES)  
 1 -- 250 mS                    3 -- 750 mS

DEFAULT VALUES FOR CODE 2		
ZONE	CODE 2	RESPONSE
1	1	ENTRY DELAY 1
2	1	ENTRY DELAY 1
3	0	INSTANT
4	0	INSTANT
5	0	INSTANT
6	0	INSTANT
7	3	24-HR INSTANT
8	3	24-HR INSTANT

**SETTING THE EXIT DELAY TIME****(Location: 30)****EXIT BEEP****0---DISABLED****1---ENABLED (DEFAULT):** The system beeps during the exit delay period**EXIT DELAY (DEFAULT: 60 seconds)****2-999 SECONDS**

The time duration can be set from 2 to 999 seconds

**SETTING THE ENTRY DELAYS****(Location: 31-32)****ENTRY DELAY LOCATIONS****31--ENTRY DELAY 1****32--ENTRY DELAY 2****ENTRY BEEP****0---DISABLED****1---ENABLED (DEFAULT):**

The system beeps during the entry delay period

**ENTRY DELAY (DEFAULT: 30 seconds, ENTRY DELAY 1 60 seconds, ENTRY DELAY 2)****2-999 SECONDS**

The time duration can be set from 2 to 999 seconds


**SETTING THE SIREN DURATION****(Location: 33)****RING BACK****0---DISABLED (DEFAULT)****1---ENABLED:** The system will activate its timing alarm output (terminal 9) to generate short beeps when the system is armed or disarmed:**1 BEEP---DISARMED 2 BEEPS---ARMED****SIREN DURATION (DEFAULT: 300 seconds)****2-999 SECONDS**

The siren duration can be set from 2 to 999 seconds

**THE KEY ENTRY PACIFIER TONES****(Location 34)**

If two or more control keypads are connected to a system, all the keypads will beep when the user codes are entered. In case that the alarm system is used for residential applications and has one of the keypads installed in the bedroom. You may find the key entry beeps are not acceptable if somebody operates the other keypad in the middle of the night.

"Location 34" allows you to program the appropriate key entry beep function.

**KEY ENTRY PACIFIER TONES****0---DISABLED:** All the key entry pacifier tones disabled**1---DISABLED:** All the key entry pacifier tones disabled except the "5 short beep" for the unsuccessful code entry warning**2---ENABLED: (DEFAULT)** - All the key entry pacifier tones enabled**SELECTION OF FORCED TO ARM OR ARM PROHIBITED****(Location: 40)****FORCED TO ARM - ARM PROHIBITED****0---FORCED TO ARM: (DEFAULT)**

Any zone that is violated will be isolated after the exit delay expired when the system is armed. The faulty zone(s) will be shown on the zone LED(s).

A **FORCED TO ARM** report will be sent if the communicator is enabled.

**WARNING:** The isolated zone is not protected.

**1---ARM PROHIBITED:**

Any zone that is faulty (open windows, malfunctioning sensor, etc.), the system will not arm. The owner will not be able to arm the system until the faulty zone is cleared or manually isolated.

5 beeps will be generated after the exit delay expired to indicate that the alarm system is not armed. The zone LED(s) will indicate the faulty zone(s). See **Arm Prohibited LED light** for more indication details.

An **ARM PROHIBITED** report will be sent if the communicator is enabled.

A faulty zone which is manually isolated after **arm prohibited** is considered as an isolated zone in normal operation. The system will be armed after the exit delay expired.

**SETTING THE HANDOVER FUNCTION**

(Location: 41)

LOCATION	ENTRY OF CODE	VALIDATION
41	0	#

**HANDOVER**

**0---DISABLED: (DEFAULT)** The system is in normal operation. All the protection zones are having their functions according to the zone configuration settings.

**1---ENABLED:** In handover condition, any delay zone is triggered first, the instant zones (Except the 24-hour zones) will be disabled during the entry delay period. With this feature, the owner can set the motion sensors for interior protection with the instant zones and the main door protection with delay zone. The system will always give instant alarm if the person does not enter the house from the main door entrance.

**TELEPHONE NUMBERS FOR COMMUNICATOR SENDING ALARM - STATUS REPORT**

(Location: 50-51)

LOCATIONS	TELEPHONE NUMBERS	VALIDATION
50	32 DIGIT MAX	#

**COMMUNICATOR LOCATIONS**

**50---MASTER TELEPHONE:** The master telephone number is the monitor station number to ring.

**51---BACKUP TELEPHONE:** The backup telephone number is intended as an alternate monitor station contact number for use when the master number fails to answer. Entering of the backup number is optional.

**THE TELEPHONE NUMBERS**

A telephone number of 32 digits maximum is allowed for each communicator location.

**NOTE:**

- The communicator is DISABLED in DEFAULT setup. Enable the communicator (Location: 80) and enter the telephone number are necessary to activate the function.
- The dialing sequence for the Master telephone and the Backup telephone is according to the setup on dialing attempts for communicator (Location: 70).
- The communicator has the priority to dial. After the communicator dialing is finished, the system will start to dial the telephone numbers in the auto-dialer.
- If backup telephone is not necessary, disable it by entering of the [Location Number], and then key-in the [#] without telephone number.
- After the line is connected, a status report or an alarm report will be sent to the monitor station in DTMF according to the communicator format stated in page 39.
- If the system is not connected to the monitor station, the communicator programming is not necessary.

**TELEPHONE NUMBERS FOR AUTO-DIALER SENDING VOICE OR NUMERIC MESSAGE**

(Location: 60-63)

LOCATIONS	ENTRY OF CODE	TELEPHONE NUMBERS	VALIDATION
60	0	32 DIGITS MAX	#

**DIALER LOCATIONS**

60---1st TELEPHONE NUMBER  
61---2nd TELEPHONE NUMBER  
62---3rd TELEPHONE NUMBER  
63---4th TELEPHONE NUMBER

**NUMERIC OR VOICE MESSAGE**

**0---NUMERIC MESSAGE:** The numeric message is the secret code of your own or the code that represents some meanings for alarm reporting that you put after the telephone number. The system will send the numeric message to your pager when alarm occurs. If numeric message is selected, no voice message will be sent on that telephone number.

**1---VOICE MESSAGE:** The system will send the recorded message to the programmed telephone number when alarm occurs.

**THE TELEPHONE NUMBERS**

A telephone number of 32 digits maximum is allowed for each dialer telephone location.

**NOTE:**

- The dialer is ENABLED in DEFAULT setup. Simply enter telephone number(s) to activate the function.
- The dialing sequence is telephone 1, 2, 3, 4. The number of dialing attempts will repeat this sequence until the attempts are reached.
- After the line is connected, the dialer will send the voice message to the telephone(s), or the numeric codes to the pager(s).
- The numeric message is considered as part of the telephone number. It is necessary to limit the code length of the telephone number plus the numeric message to 32 digits maximum.
- No listen-in function is available, when the location is programmed for sending numeric message.
- If less than 4 telephones are required for alarm reporting, just delete those locations with its [Location Number] and key-in [#] without telephone number.

**PUTTING PAUSE TO A TELEPHONE NUMBER**

On programming of the telephone numbers for communicator and auto-dialer, dialing pause can be put into a telephone number during number entry. Maximum 5 pauses can be allowed for one telephone number and they can be put at any position of the number; beginning, ending and between digits are all possible.

START	TIME DURATION	STOP
PAUSE	1 - 99	PAUSE

Press [PAUSE] key to start the pause time

The pause duration can be 1 to 99 seconds

Press [PAUSE] key again to end the pause time

## WHY PAUSE IS NECESSARY

Allowing pause in telephone number programming is very important in some applications. Otherwise, the communication between the alarm system and the receiving party is not possible. Such as dialing to an auto-pager station, or dialing out through an PABX extension line (only for those PABX systems accept standard tone dialing telephones can be used).


## WHEN PAUSE IS REQUIRED

### 1) Dialing to an auto-pager station from the auto-dialer

When the system dials to an auto-pager station, and the line is through. The pager station will reply with a message, such as **Welcome to use ABC company auto-paging service...., please enter your personal code after the beep.** Usually this message lasts for 20 to 30 seconds. If the system sends the status report or the numeric data immediately after the line is through, before the end of the message, the data will be lost or the auto-pager station can not recognize the calling party and refuse to make a call.

To know the length of the replying message, you can dial to the auto-pager station and count the time while you are listening to the message. For example, the time that you have counted is 23 seconds which will be the pause time required. To allow tolerance, we suggest making a pause time of 25 seconds before sending the numeric message after the line is through.

The following is the programming example of sending a numeric message to an auto-pager station.




#### NOTE:

- The total number of digits of the telephone number and the numeric message is 32 digits maximum.
- Only the numeric message will be displayed on your pocket pager.

### 2) Sending an alarm report to your auto-pager from communicator

If your pocket pager has 20 digits or more space to receive data, with the pause function, you can request the system to send the alarm report to your pager as a back-up report while the system sends report to the monitor station.

The code of entries for the programming are as follows:




#### NOTE:

The display of the alarm report on your pager is according to the communicator alarm report format. See page 39 for details.

### 3) Sending voice message/alarm report via an PABX system

If your alarm system is connected to one of the extension lines of an PABX system, the communicator/dialer usually requires to dial a number first (usually a "9" or "0") and waits around 1-2 seconds to pick up an external line before it can dial the telephone number for alarm reporting.

The code of entries for the system dialing via an PABX system are as follows:



**NOTE:**

- 1) Connecting the dialer/communicator to an PABX system is usually not recommended, unless direct line is not available.
- 2) Only the PABX system that accepts standard tone dialing telephone as extension unit can be used.

**FUNCTION KEYS CORRESPONDING TO DTMF SYMBOLS "\*" AND "#" & INSTRUCTION FOR SENDING REPORT**

In some services may require the use of DTMF codes corresponding to the "\*" or "#" symbol when sending numeric short message to the service center or pager station. The following are the function keys may be required in programming for code entry in locations 50-51 and 60-63.

**HOME** **#** Equivalent to the DTMF code of "#"

**HOME** **\*** Equivalent to the DTMF code of "\*"

**BYPASS** The instruction for the Communicator to send the alarm status report

**DIALING ATTEMPTS FOR COMMUNICATOR (Location: 70)**

LOCATION ENTRY OF CODE VALIDATION  
**70** **1** **#**

**DIALING ATTEMPTS** (DEFAULT: 4)

1 to 8 dialing attempts are possible

**NOTE:**

The system will make the number of dialing attempts to the master telephone number as programmed. Where the backup telephone number has been enabled the dialing attempts are split into the following sequence:

TELEPHONE NUMBER	2 ATTEMPTS	3 ATTEMPTS	4 ATTEMPTS	5 ATTEMPTS	6 ATTEMPTS	7 ATTEMPTS	8 ATTEMPTS
MASTER TELEPHONE	1,2	1,2	1,2	1,2,5	1,2,5,6	1,2,5,6	1,2,5,6
BACKUP TELEPHONE	----	3	3,4	3,4	3,4	3,4,7	3,4,7,8

- \* Minimum dialing attempts of 3 are required if backup number is enabled
- \* The interval for dialing attempt for different telephone number is 5 seconds while for the same telephone number is 60 seconds

**DIALING ATTEMPTS FOR AUTO-DIALER (Location: 71)**

LOCATION ENTRY OF CODE VALIDATION  
**71** **1** **#**

**DIALING ATTEMPTS** (DEFAULT: 4)

1 to 8 dialing attempts are possible

**NOTE:**

The dialing sequence is telephone 1,2,3,4. The number of dialing attempts will repeat this sequence until the attempts are reached.

- \* The interval for dialing attempt for different telephone number is 5 seconds while for the same telephone number is 60 seconds

**MESSAGE REPEATS****(Location: 72)**

LOCATION ENTRY OF CODE VALIDATION  
**72** **1** **#**

**MESSAGE REPEATS** (DEFAULT: 4)  
 1 to 8 message repeats are possible

**NOTE:**

After dialing and the line is through, the dialer pauses for 5 seconds and then transmits the recorded message. Every time the message finished, the dialer waits 3 seconds for the called party to acknowledge (the acknowledgement signal is DTMF 1, press the 1 button on the telephone which is a tone dialing telephone). Without an acknowledgement, the message will be repeated until the maximum number of message repeats are reached. The dialer will call the remaining numbers and will then retry the number(s) that did not acknowledge repeatedly until the maximum number of dialing attempts are reached.

**SELECTION OF BACKUP OR NON-BACKUP REPORTING****(Location: 73)**

LOCATION ENTRY OF CODE VALIDATION  
**73** **0** **#**

**REPORTING MODE**

0---NON-BACKUP MODE (DEFAULT)

1---BACKUP MODE

**NOTE:**

- The selected reporting mode for the system governs both the communicator and the auto-dialer sections. However, the acknowledgement required by the two sections are separated and independent.

**• NON-BACKUP REPORTING MODE**

- a) On non-backup reporting mode, the COMMUNICATOR must receives an acknowledgement signal DTMF 1 each from the master monitor station and the backup monitor station before the current event is considered to be reported and closed.

For the application requires the alarm report sending to both the master monitor station and the backup monitor station, the selection of non-backup reporting mode is required.

- b) On non-backup reporting mode, the DIALER must receives an acknowledgement signal DTMF 1 from each telephone in the group of 4 before the current event is considered to be reported and closed.

**• BACKUP REPORTING MODE**

- a) On backup reporting mode, the COMMUNICATOR receives an acknowledgement signal DTMF 1 from the master monitor station is sufficient to consider the current event closed and call off the communicator session. The backup number there (the 2nd monitor station) is for backup purpose only in the case that the master number is out of order.

- b) On backup reporting mode, the DIALER receives an acknowledgement signal DTMF 1 from a SINGLE telephone in a group of 4 is sufficient to consider the current event closed and call off the dialer session. The remaining 3 telephones are there for backup purpose only.



**THE LISTEN-IN FUNCTION ENABLE AND DURATION PROGRAMMING (Location: 74)**

LOCATION	ENTRY OF CODE	VALIDATION
74	0	#

**LISTEN-IN FUNCTIONS / DURATION****0---DISABLED****1-99---SECONDS (DEFAULT: 60 seconds):** 1 to 99 seconds, listen-in duration**NOTE:**

The listen-in function is available only on the auto-dialer section. At the end of the recorded voice message after a short beep, the dialer waits 3 seconds for the called party to acknowledge (DTMF 1). Upon receipt of the acknowledgement signal, the dialer removes the presently contacted telephone from its task list for the current event. This is the response of the system for listen-in function DISABLED. If the listen-in function is permitted, the dialer enables the listen-in for a pre-programmed period of time after acknowledgement.

At the end of the listen-in period, a short beep sounds. If [1] is keyed by the called party within 10 seconds, a new listen-in period begins. Without keying [1] the dialer will go **on hook** after 10 seconds. The listen-in period may be prolonged as many times as necessary or terminated by keying [9] after the short beep.

**ARM-DISARM REPORT****(Location: 76)**

LOCATION	ENTRY OF CODE	VALIDATION
76	0	#

**ARM-DISARM REPORT****0---DISABLED (DEFAULT)****1---ENABLED****NOTE:**

- 1) On report enabled condition, the system will send an arming or disarming report to the monitor station each time when it is armed or disarmed.
- 2) Most of the alarm systems for office are disarmed at the morning and are armed at the evening; and those alarm systems for home are just opposite. If all the systems are sending the arm-disarm reports to the monitor station at the same time, there may not be enough telephone lines at the station to handle all the incoming reports.  
Please consult your monitor station and have their permission first before enabling this function to prevent signal jammed.
- 3) No matter the selection is **DISABLED** or **ENABLED**. The system will always send Status report on **ARM PROHIBITED** or **FORCED TO ARM** condition after the exit delay expired if any protection zone is abnormal.

**SELECTION OF DIALING COMBINATION****(Location: 80)**

LOCATION	ENTRY OF CODE	VALIDATION
80	0	#

**THE DIALING COMBINATIONS****0---COMMUNICATOR AND DIALER OFF****1---COMMUNICATOR AND DIALER ON****2---COMMUNICATOR OFF, DIALER ON (DEFAULT)****3---COMMUNICATOR ON, DIALER OFF****NOTE:**

- 1) Select **Communicator and Dialer OFF** for the system that is not connected to any monitor station or telephone for alarm reporting.
- 2) Select **Communicator and Dialer ON** for the system that is connected to both monitor station and telephones for alarm reporting.  
The communicator has the priority to dial. After the communicator dialing is finished, the system will start to dial the telephone numbers for the dialer.
- 3) Select **Communicator OFF, Dialer ON** for the system that is only connected to telephones for alarm reporting with voice or numeric message.
- 4) Select **Communicator ON, Dialer OFF** for the system that is only connected to monitor station.

**SELECTION OF DIALING MODE FOR CALLING THE TELEPHONE CENTRAL OFFICE****(Location: 81)**

LOCATION	ENTRY OF CODE	VALIDATION
81	0	#

**DIALING MODES****0----STANDARD DTMF (DEFAULT)****1----PULSE, 33.3/66.6 10PPS****2----PULSE, 33.3/66.6 20PPS****3----PULSE, 40/60 10PPS****NOTE:**

- 1) The dialing mode selected is for both the communicator and the dialer sections.
- 2) Select the right dialing mode to match the local telephone network system for the communication.
- 3) If pulse dialing mode is selected, the communicator dials the telephone number in pulse mode to make contact with the monitor station. After the line is through, the communicator still sends the alarm report to the monitor station in DTMF signal.
- 4) The system can only accept DTMF signal for remote arm/disarm control and making acknowledgement. Some of the feature that requires DTMF signal will be lost in the pulse telephone system.

**NUMBERING BEEP TONES FOR CONTROL PANEL IDENTIFICATION (Location: 82)**

LOCATION	ENTRY OF CODE	VALIDATION
82	0	#

**IDENTIFICATION BEEP TONES****0----DISABLED (DEFAULT):** The system is using the voice chip for alarm reporting.**1----CONTINUOUS 1-BEEP TONES, NO VOICE MESSAGE****2----CONTINUOUS 2-BEEP TONES, NO VOICE MESSAGE****3----CONTINUOUS 3-BEEP TONES, NO VOICE MESSAGE****NOTE:**

- 1) The purpose of the numbering beep tones is designed to replace the voice message in those low cost version panels which have no voice chip to store the voice message to identify the alarm system.
- 2) It is always advised to disable the numbering function for those panels equipped with voice chip, unless, the numbering beep tones are considered to be more suitable for a specific application. Once the beep tone function is enabled, it will replace the voice message for alarm reporting.
- 3) The owner can use the number of beeps to identify the alarm system located if he has more than one alarm systems in his installations, such as has alarm systems at office, home and holiday house etc.

- 4) Alarm reporting with numbering beep tones is that, after the line is through, the dialer pause for 5 seconds and then transmits the numbering beep tones for 20 seconds. Every time the 20 seconds beep tones finished, the dialer waits 3 seconds for the called party to acknowledge (the acknowledgement signal is DTMF 1). Without an acknowledgement, the 20 seconds beep tones will repeat as the programmed number of message repeats (at location 72, 1 to 8 message repeats are possible). The dialer will call the remaining telephone numbers and will retry the number(s) that did not acknowledge repeatedly until the maximum number of dialing attempts are reached.

**NUMBER OF RINGS TO PICK-UP TELEPHONE LINE ON REMOTE ACCESS (Location: 83)**

LOCATION	ENTRY OF CODE	VALIDATION
83	0	#

**NUMBER OF RINGS TO PICK-UP TELEPHONE LINE****0-----DISABLED:** Remote access is not allowed.**1-99---RINGS (DEFAULT: 16):** 1 to 99 number of rings are possible**NOTE:**

- 1) The system has been designed to allow the owner to telephone the system remotely to check its arm-disarm status, to make arm-disarm control or to request the communicator for a current status report sending to the monitor station or to the owner's pocket pager.
- 2) In most cases that the telephone number of the system connected is the home telephone number of the owner. To set appropriate number of rings to pick-up the line is important to those systems using the home telephone line. The system will always pick-up the line before you pick-up the phone in daily use if you set too less number of rings. For the setting of too many number of rings, the owner has to wait a long time for the system to pick-up the line to accept remote access.
- 3) A system that has dedicated telephone line for communication can be set with 2 to 3 rings to pick-up the line to speed up the access.
- 4) Some of the telephone networks do not accept too many number of rings and cut the line before the number of rings are reached. If that be the case, immediately hang up and call the system back. The system remembers the number of rings for 45 seconds after a call attempt has been terminated. It will continue to count rings through repeated attempts until the number of rings have occurred.
- 5) Please see page 10, D.T. JUMPER setting for more information.

**PERIODIC REPORT****(Location: 84)**

LOCATION	ENTRY OF CODE	VALIDATION
84	0	#

**PERIODIC REPORT****0---DISABLED (DEFAULT)****1---GIVES STATUS REPORT EVERY 12 HOURS****2---GIVES STATUS REPORT EVERY 24 HOURS****3---GIVES STATUS REPORT EVERY 7 DAYS****NOTE:**

- 1) To enable the periodic report is optional.
- 2) Periodic report may not be necessary if the system is for daily use.
- 3) If the alarm system is left in a place for a period of time without arm-disarm control. Such as the owner is on holiday for few weeks, to make sure it works properly during that period, the owner can set the system to give periodic report.
- 4) The period report shows the current status of the system when the report is sent. The report is based on the communicator format shown on page 39, which can be sent to the monitor station and / or to the owner's pocket pager.
- 5) The periodic report counting starts at the time when the system is powered up.

**POWER-UP DELAY****(Location: 85)**

LOCATION	ENTRY OF CODE	VALIDATION
85	0	#

**POWER-UP DELAY****0---DISABLED (DEFAULT)****1---ENABLED****NOTE:**

- 1) The purpose of power-up delay is to give a period of time for the system to stabilize and to charge up the backup battery after power-up at the first time, or power-up after a long time of AC power failure and the backup battery is completely exhausted.
- 2) The power-up delay is 5 minutes. The system suppresses all the alarm outputs including the communicator and the dialer.
- 3) During the power-up delay period, the **AC POWER** and the **BATTERY** LED lights are flashing alternatively.
- 4) The system will send a status report to the monitor station 5 minutes after power up if the communicator is enabled.

**PERIODIC BATTERY TEST****(Location: 86)**

LOCATION	ENTRY OF CODE	VALIDATION
86	0	#

**PERIODIC BATTERY TEST****0---DISABLED (DEFAULT)****1---DAILY-24 HOURS****2---WEEKLY-7 DAYS****NOTE:**

- 1) When PERIODIC battery testing is selected, the system will dynamically test the backup battery every 24 hours or every 7 days. The time counting starts at the system power-up.
- 2) Every time after the testing, the system shows the battery status on the control console. Under some certain circumstances, it also sends a status report to the monitor station:
  - a) The battery is LOW
  - b) The battery resumes normal but it was LOW in the last testing.
 There is no status report sending to the monitor station if the battery is normal and it was normal as well in the last testing.
- 3) The system will automatically stop the battery testing in AC power failure condition, or, when the system is in alarm.

**DIAL-TONE AND TELEPHONE LINE FAULT DETECTS****(Location: 87)**

LOCATION	ENTRY OF CODE	VALIDATION
87	0	#

**DIAL-TONE AND TELEPHONE LINE FAULT DETECTS****0---DISABLED****1---ENABLED (DEFAULT)****NOTE:**

- A) Under the **DISABLED** condition, the system has the following manners to the telephone line:
  - 1) The communicator or the dialer makes dialing right away 4 seconds after getting the line.
  - 2) No telephone line fault detect function at system arm-disarm control.
- B) Under the **ENABLED** condition, the system has the following manners to the telephone line:
  - 1) The communicator or the dialer waits for the dial-tone and starts dialing if uninterrupted tone is detected for 4 seconds. If 6 seconds elapse with no dial tone, the communicator or the dialer disengages the line, waits 5 seconds and tries again. If another 6 seconds go by without dial tone, dialing starts anyway.
  - 2) Telephone line fault detect is performed every time at system arm-disarm control. The line is considered to be normal if uninterrupted dial-tone is detected for 4 seconds. The following indications will be given if the line is faulty:
    - a) Continuous 5 beep tones
    - b) The **DIALING** LED flashing

C) Please see page 10, D.T. JUMPER setting for more information.

**To stop the line fault warning beep tones:**

- Check the telephone line and its plug and socket, make sure the line is firmly connected. Try to make system arm-disarm control again to perform a new line fault test. If the line resumes normal, the beep tones will stop and the **DIALING** LED will revert to standby state.
- If the line is faulty due to the telephone network, the only way to stop the warning beep tones is to set the system on **DISABLE** state by programming.

**SET THE HABITUAL BYPASSED ZONES IN MEMORY FOR "HOME" MODE**

(Location: HOME)

LOCATION	ENTRY OF CODE	VALIDATION
HOME	1 TO 8	#

**ZONES PUTTING INTO MEMORY FOR BYPASS**

1-8---(DEFAULT: NIL): Key-in the zone numbers (zone 1 – zone 8) for bypass.

**NOTE:**

- Entering the zone number(s) required to be bypassed one by one into the memory. Continuous entry is possible.

**Example:** The key-in procedures of putting the zones 1,2 and 4 into memory for bypass for home operation are as follows:

PRESS **HOME** **1** **2** **4** **#**

**WARNING:** Making bypass to the 24 hour zone is not recommended. A bypassed zone is not protected.

- Putting the habitual bypassed zones in memory is convenient for the owner to set the system for **HOME** mode operation instantly. The owner does not require to set the zones one by one every time to make them isolated. With the habitual bypassed zones stored in memory, the owner simply key-in the [User Code], then press the [HOME] and [#] keys to make the system in home operation with the required zones bypassed.

**RECORD THE VOICE MESSAGE FOR REPORTING ALARMS (Location: RECORD)**

LOCATION	VALIDATION
RECORD	#

The Master Control Console is equipped with the [RECORD] key and the microphone on the panel.

To make recording, press the [RECORD] key followed immediately by the [#] key. The recording LED light will be ON indicating the beginning of the recording time and it will hold for 20 seconds until the end of the recording time.

**RECORDING THE VOICE MESSAGE**

- The message usually put into an alarm system is an identification message for alarm reporting. Please write down your message on a paper and try to read it aloud & clearly with a steady speed and keep the time in 20 seconds. Practice the message until you can read it within the time limit.
- When the RECORD LED is ON steadily (*recording starts*), read the 20 seconds message aloud, with your face about 30 cm (1 ft.) from the microphone. The LED light will stop automatically when 20 seconds expired and your message is stored.
- Recording can be repeated as many times as you like until the message is in your satisfaction. The newly recorded message replaces the old one.

**SETTING THE SYSTEM WITH DEFAULT VALUES**

(Location: 02)

**WARNING:** When set the system with the default programme, except the voice message and the Master Code, all the values programmed previously will be cleared and replaced by the default values that shown on the **Default Data Chart** on page 13.

Key-in the programming location followed immediately with the [#] key, the system starts to down load the default values into its memory, which takes around 2 seconds. After that, the default values on the **default Data Chart** are entered.

LOCATION	VALIDATION
02	#

**EXIT THE PROGRAMMING MODE**

After programming is finished, the system has to be set to exit the programming mode and back to operation mode. Exit the programming mode can be done at anytime by pressing the [\*] key twice.

VALIDATION
* *

# PROGRAM SUMMARY CHART

LOCATION NO.	DESCRIPTION OF PARAMETERS	ENTRY LIMITS AND CODE OPTIONS	PROGRAMMING FORMAT	FACTORY DEFAULT	YOUR PROGRAM RECORD
01	Master Code	2-5 DIGITS	<b>01</b> <b>MASTER CODE</b> <b>#</b>	NONE	
02	Factory default values	<b>WARNING:</b> With the entry of this location, all the values previously programmed will be cleared and replaced by factory default values except the voice message and the master code		SEE THE DEFAULT VALUES IN THIS COLUMN	
10	Client code	4 Digits	<b>10</b> <b>CLIENT CODE</b> <b>#</b>	0000	
11	User code 1	2-5 Digits	<b>11</b> <b>USER CODE 1</b> <b>#</b>	NONE	
12	User code 2		<b>12</b> <b>USER CODE 2</b> <b>#</b>	NONE	
13	User code 3		<b>13</b> <b>USER CODE 3</b> <b>#</b>	NONE	
14	User code 4		<b>14</b> <b>USER CODE 4</b> <b>#</b>	NONE	
15	User code 5		<b>15</b> <b>USER CODE 5</b> <b>#</b>	NONE	
16	User code 6		<b>16</b> <b>USER CODE 6</b> <b>#</b>	NONE	
17	User code 7		<b>17</b> <b>USER CODE 7</b> <b>#</b>	NONE	
18	User code 8		<b>18</b> <b>USER CODE 8</b> <b>#</b>	NONE	
21	Configuration of zone 1	<b>CODE 1: 0 or 1</b> 0--Single Trigger 1--Multiple Trigger <b>CODE 2: 0,1,2,3 or 4</b> 0--Instant 1--Entry Delay 1 2--Entry Delay 2 3--24-Hour Instant 4--24-Hour Silent Panic <b>CODE 3: 0,1,2 or 3</b> 0--25mS 1--250mS 2--500mS 3--750mS	<b>21</b> <b>CODE 1</b> <b>CODE 2</b> <b>CODE 3</b> <b>#</b>	CODE 1=1 CODE 2=1 CODE 3=2	
22	Configuration of zone 2		<b>22</b> <b>CODE 1</b> <b>CODE 2</b> <b>CODE 3</b> <b>#</b>	CODE 1=1 CODE 2=1 CODE 3=2	
23	Configuration of zone 3		<b>23</b> <b>CODE 1</b> <b>CODE 2</b> <b>CODE 3</b> <b>#</b>	CODE 1=1 CODE 2=0 CODE 3=2	
24	Configuration of zone 4		<b>24</b> <b>CODE 1</b> <b>CODE 2</b> <b>CODE 3</b> <b>#</b>	CODE 1=1 CODE 2=0 CODE 3=2	
25	Configuration of zone 5		<b>25</b> <b>CODE 1</b> <b>CODE 2</b> <b>CODE 3</b> <b>#</b>	CODE 1=1 CODE 2=0 CODE 3=2	
26	Configuration of zone 6		<b>26</b> <b>CODE 1</b> <b>CODE 2</b> <b>CODE 3</b> <b>#</b>	CODE 1=1 CODE 2=0 CODE 3=2	
27	Configuration of zone 7		<b>27</b> <b>CODE 1</b> <b>CODE 2</b> <b>CODE 3</b> <b>#</b>	CODE 1=1 CODE 2=3 CODE 3=2	
28	Configuration of zone 8		<b>28</b> <b>CODE 1</b> <b>CODE 2</b> <b>CODE 3</b> <b>#</b>	CODE 1=1 CODE 2=3 CODE 3=2	
30	Exit delay and exit beep	<b>CODE: 0 or 1</b> 0--Exit Beep Disabled 1--Exit Beep Enabled <b>EXIT DELAY:</b> 2-999 Seconds	<b>30</b> <b>CODE</b> <b>SECONDS</b> <b>#</b>	CODE=1 60 Seconds	

## PROGRAMMING SUMMARY CHART (CONTINUED)

LOCATION NO.	DESCRIPTION OF PARAMETERS	ENTRY LIMITS AND CODE OPTIONS	PROGRAMMING FORMAT	FACTORY DEFAULT	YOUR PROGRAM RECORD
31	Entry delay 1 and entry beep	<b>CODE: 0 or 1</b> 0--Entry Beep Disabled 1--Entry Beep Enabled <b>ENTRY DELAY 1:</b> 2-999 Seconds	<b>31</b> <b>CODE</b> <b>SECONDS</b> <b>#</b>	CODE=1 30 Seconds	
32	Entry delay 2 and entry beep	<b>CODE: 0 or 1</b> 0--Entry Beep Disabled 1--Entry Beep Enabled <b>ENTRY DELAY 2:</b> 2-999 Seconds	<b>32</b> <b>CODE</b> <b>SECONDS</b> <b>#</b>	CODE=1 60 Seconds	
33	Siren duration and ring back	<b>CODE: 0 or 1</b> 0--Ring Back Disabled 1--Ring Back Enabled <b>SIREN DURATION:</b> 2-999 Seconds	<b>33</b> <b>CODE</b> <b>SECONDS</b> <b>#</b>	CODE=0 300 Seconds	
34	The key entry pacifier tones	<b>CODE: 0, 1 or 2</b> 0--Disabled 1--Disabled, except the unsuccessful code entry warning 2--Enabled	<b>34</b> <b>CODE</b> <b>#</b>	2 (Enabled)	
40	Forced to arm or arm prohibited	<b>CODE: 0 or 1</b> 0--Forced to Arm Mode 1--Arm Prohibited Mode	<b>40</b> <b>CODE</b> <b>#</b>	0 (Forced to arm)	
41	Handover or non-handover mode	<b>CODE: 0 or 1</b> 0--Non-handover Mode 1--Handover Mode	<b>41</b> <b>CODE</b> <b>#</b>	0 (Non-handover)	
50	Master telephone number for communicator	32 Digits	<b>50</b> <b>NUMBER</b> <b>#</b>	NONE	
51	Backup telephone number for communicator		<b>51</b> <b>NUMBER</b> <b>#</b>	NONE	
60	1st telephone number for dialer	<b>CODE: 0 or 1</b> 0--Numeric Message 1--Voice Message <b>TELEPHONE NUMBER:</b> 32 Digits	<b>60</b> <b>CODE</b> <b>NUMBER</b> <b>#</b>	NONE	
61	2nd telephone number for dialer		<b>61</b> <b>CODE</b> <b>NUMBER</b> <b>#</b>	NONE	
62	3rd telephone number for dialer		<b>62</b> <b>CODE</b> <b>NUMBER</b> <b>#</b>	NONE	
63	4th telephone number for dialer		<b>63</b> <b>CODE</b> <b>NUMBER</b> <b>#</b>	NONE	
	Pause time for inserting between digits, putting before and after the number in communicator and dialer programming	1-99 Seconds	<b>PAUSE</b> <b>SECONDS</b> <b>PAUSE</b>	NONE	
70	Number of dialing attempts for communicator	1-8 Attempts	<b>70</b> <b>NUMBER</b> <b>#</b>	4	
71	Number of dialing attempts for dialer	1-8 Attempts	<b>71</b> <b>NUMBER</b> <b>#</b>	4	
72	Number of message repeats	1-8 Repeats	<b>72</b> <b>NUMBER</b> <b>#</b>	4	



LOCATION NO.	DESCRIPTION OF PARAMETERS	ENTRY LIMITS AND CODE OPTIONS	PROGRAMMING FORMAT	FACTORY DEFAULT	YOUR PROGRAM RECORD
73	Backup or non-backup reporting	<b>CODE: 0 or 1</b> 0---Non-backup 1---Backup	<b>73</b> <b>CODE</b> <b>#</b>	0 (Non-backup)	
74	Listen-in duration	1-99 Seconds 0---Listen-in Disabled	<b>74</b> <b>SECONDS</b> <b>#</b>	60 Seconds	
76	Arm-disarm reports	<b>CODE: 0 or 1</b> 0---Disabled 1---Enabled	<b>76</b> <b>CODE</b> <b>#</b>	0 (Disabled)	
80	Dialing combination for communicator and dialer	<b>CODE: 0, 1, 2 or 3</b> 0---Communicator & Dialer OFF 1---Communicator & Dialer ON 2---Communicator OFF, Dialer ON 3---Communicator ON, Dialer OFF	<b>80</b> <b>CODE</b> <b>#</b>	2 (Communicator OFF, Dialer ON)	
81	Dialing medium	<b>CODE: 0, 1, 2 or 3</b> 0---Standard DTMF 1---33.3/66.6 10pps. 2---33.3/66.6 20pps. 3---40/60 10pps	<b>81</b> <b>CODE</b> <b>#</b>	0 (DTMF)	
82	Using beep tones to replace the voice message	<b>CODE: 0, 1, 2 or 3</b> 0---Voice Message 1---1 Beep Continuous 2---2 Beep Continuous 3---3 Beep Continuous	<b>82</b> <b>CODE</b> <b>#</b>	0 (Voice Message)	
83	Number of rings to pick-up telephone line	1-99 Rings 0---Call in Disabled	<b>83</b> <b>NUMBER</b> <b>#</b>	16	
84	Periodic report	<b>CODE: 0, 1, 2 or 3</b> 0---No Report Function 1---Sends Status Report Every 12 Hours 2---Sends Status Report Every 24 Hours 3---Sends Status Report Every 7 Days	<b>84</b> <b>CODE</b> <b>#</b>	0 (Disabled)	
85	Power-up delay	<b>CODE: 0 or 1</b> 0---Disabled 1---Enabled	<b>85</b> <b>CODE</b> <b>#</b>	0 (Disabled)	
86	Periodic battery testing	<b>CODE: 0, 1 or 2</b> 0---Periodic Testing Disabled 1---Test Every 24 Hours 2---Test Every 7 Days	<b>86</b> <b>CODE</b> <b>#</b>	0 (Disabled)	
87	Line fault and dial tone detects	<b>CODE: 0 or 1</b> 0---Disabled 1---Enabled	<b>87</b> <b>CODE</b> <b>#</b>	1 (Enabled)	
HOME	Bypassed zones in memory	ZONES: 1,2,3,4,5,6,7 and 8	<b>HOME</b> <b>ZONES</b> <b>#</b>	NONE	
RECORD	Recording the alarm reporting message	20 Seconds Fixed	<b>RECORD</b> <b>#</b>	NONE	

**REMARKS:**
**● Entering to programming mode**

Whenever programming is required, it is necessary to set the system into programming mode first by entering the master code and validate by pushing the [\*] key twice:

**MASTER CODE** [\*] [\*]

**● Leaving the programming mode**

Whenever the programming is finished, simply push the [\*] key twice to leave the programming mode:


[\*] [\*]

## COMMUNICATOR ALARM-STATUS REPORT FORMAT

The communicator of the HA-268 is using the most popular medium, DTMF, in data communication. Which allows the system owner to set up a private monitor station if he has several systems installed; or the installer to set up a proprietary monitor station for the small to medium size community for his clients with a personal computer through a Standard Voice Modem.

The owner or the installer can prepare an alarm monitoring software on his preference by himself according to the stated alarm-status report format with the source codes provided; or use the AEI standard software **MS-980** for the station.

The communicator sends the report 5 seconds (*additional time can be made via pause programming if necessary*) after the line is connected to the monitor station. The report can also be sent directly to a pocket auto-pager (*minimum 20-digit display required*) with the pager's phone number and the appropriate pause time programmed.



## DESCRIPTION OF THE REPORT PARAMETERS (THE SOURCE CODES)

### CLIENT ID

The client ID is the client's identification number, which must be a 4-digit number.

### USER NUMBER

8 user ID numbers are available for operating of the alarm system. The latest user who operates the system will be recorded in the report.

**NOTE:** Utilizing of the key switch to arm-disarm the system is always considered as user 1 in the report.

### ZONE STATUS CODES

The system shows the status of each protection zone with the status code in the report for all 8 zones.

- 0---The zone is normal.
- 1---The zone is MANUALLY ISOLATED by the user.
- 2---Alarm is occurred, an INSTANT ALARM zone.
- 3---Alarm is occurred, an ENTRY DELAY 1 alarm zone.
- 4---Alarm is occurred, an ENTRY DELAY 2 alarm zone.
- 5---Alarm is occurred, a 24-HOUR INSTANT alarm zone.
- 6---Alarm is occurred, a 24-HOUR SILENT PANIC alarm zone.
- 8---The zone is in ALARM MEMORY, alarm was occurred.
- 9---The zone is ABNORMAL, the system is forced to arm or arm prohibited.

### SYSTEM STATUS CODES

The 7 digit system status code represents 7 events in the system. The alarm report always reflects the current status of the system, and that the report made by call for status from a telephone always reflects the status of the latest events of the system.

#### A: 0---NO ALARM

9---ALARM OCCURRED: Alarm occurred at any hardware zone or software zone. TAKING ACTION IS REQUIRED

#### B: 0---SYSTEM DISARMED:

Only the 24-hour zones and the software zones are effective. 9---SYSTEM ARMED: All the hardware and software zones are effective if the protection zones are normal.

#### C: 0---AC NORMAL

1---AC FAILURE: AC power is not supplied, system is using battery.

#### D: 0---ARMED NORMALLY:

The system is armed normally, the protection zones are normal or the faulty zone(s) is manually isolated.

#### 1---FORCED TO ARM:

The system is forced to arm due to faulty zone(s) existing. Checking the **zone status** report for the faulty zone(s) which is indicated on its location with the zone status code, number 9, zone abnormal.

#### 2---ARM PROHIBITED:

The system is not armed after the exit delay expired due to faulty zone(s) existing. Check the **zone status** report for the faulty zone(s) which is indicated on its location with the zone status code, number 9, zone abnormal.

#### E: 0---DURESS NORMAL

#### 1---DURESS ALARM:

The duress code is keyed-in. The system activates the communicator and the auto-dialer for alarm reporting but gives no local alarm. This is a software zone.

**F: 0---PANIC NORMAL**
**1---PANIC ALARM:**

The system is activated to give alarm by panic button (press any two keys on the control console simultaneously for more than 3 seconds). This is a software zone.

**G: 0---BATTERY NORMAL**
**1---BATTERY LOW:**

The back-up battery is low. Call the service department.

**• CHECK SUM**

The check sum is a number of the last 2 digits of the sum of all the numbers (total 20 digits) in the report added together. It is a tool for the monitor station to check whether all the data in the report are received correctly.

**THE ACKNOWLEDGEMENT SIGNAL FOR COMMUNICATOR**

At the end of the 22 digits (including the check sum) of the source codes in the alarm status report have been sent out, the communicator waits 3 seconds for the monitor station to acknowledge, the acknowledgement signal required is an DTMF 1. Upon receipt of the acknowledgement signal, the communicator considers that the event is reported and closed. Without an acknowledgement, the communicator will retry the number(s) that did not acknowledge repeatedly until the maximum number of dialing attempts are reached.

**INTERPRETING THE REPORT - EXAMPLES**
**1. An Alarm Report**

CLIENT	USER	ZONES	SYSTEM STATUS	CHECKSUM
6288	1	00109020	9901000	56
		1 2 3 4 5 6 7 8	A B C D E F G	

The report is from client number 6288. The system is armed by user 1, zones 1, 2, 4, 6 and 8 are normal, zone 3 is manually isolated, zone 5 is faulty, zone 7 which is in alarm is an instant alarm zone, action is required due to alarm occurred, system is in armed mode. AC is normal, the system is forced to arm due to faulty zone (zone 5) existing, duress zone is normal, panic zone is normal, battery is normal, and that the check sum is 56 which is correct.

**2. A Duress Alarm Report**

CLIENT	USER	ZONES	SYSTEM STATUS	CHECKSUM
9756	2	00000000	9000100	39
		1 2 3 4 5 6 7 8	A B C D E F G	

The report is from client number 9756, the system was disarmed by user 2, all protection zones are normal, alarm occurred and taking action is required, system is in disarmed mode. AC is normal, system is normal with no faulty zone. Duress zone is in alarm, panic zone is normal, battery is normal, and that the check sum is 39 which is correct.

**3. A Report is Requested by Means of Call For Status**

CLIENT	USER	ZONES	SYSTEM STATUS	CHECKSUM
8321	6	00000080	0000000	28
		1 2 3 4 5 6 7 8	A B C D E F G	

The report is from client 8321, the system was disarmed by user 6, all protection zones are normal except zone 7 is in alarm memory because alarm was occurred, no alarm is occurred, system is in disarmed mode. AC is normal, system is normal with no faulty zone, duress zone is normal, panic zone is normal, battery is normal, and that the check sum is 28 which is correct.

**ALARM--SYSTEM STATUS--TESTING EVENTS REPORTING MEDIA SUMMARY CHART**

REPORTING MEDIA ALARM EVENTS	LOCAL ALARM (SIREN/STROBE)	AUTO-DIALER	COMMUNICATOR
DELAY ZONES	✓	✓	✓
INSTANT ZONES	✓	✓	✓
24-HR INSTANT ZONES	✓	✓	✓
24-HR SILENT ZONES	—	✓	✓
PANIC	✓	✓	✓
DURESS	—	✓	✓
TAMPER SWITCH	✓	✓	✓
SYSTEM STATUS EVENTS			
FORCED TO ARM	—	—	✓
ARM PROHIBITED	—	—	✓
BATTERY LOW	—	—	✓
AC POWER FAILURE	—	—	✓
SYSTEM ARM-DISARM	—	—	✓
PERIODIC REPORT	—	—	✓
REQUESTING A STATUS REPORT	—	—	✓
TESTING EVENTS			
ALARM OUTPUT TESTING	✓	—	—
AUTO-DIALER TELEPHONE NO. TESTING	—	✓	—
COMMUNICATOR TELEPHONE NO. TESTING	—	—	✓

**REMARK:** Assume that all the program options for communicator and auto-dialer are enabled.

## ACCESS THE SYSTEM REMOTELY

The HA-268 may have been set up to allow the owner to telephone the system (See *Program Location 83*) to determine of its present status or to request a detailed status report. Configured this way you can also turn the system arm or disarm remotely by telephone. The call can be made from any telephone capable of tone dialing, including DTMF capable mobile telephones.

For obvious security reasons the system only allows to use USER CODE 1 for remote arm-disarm control.

The system generates different answering beeps to response to the access from the remote telephone. The owner can key-in the appropriate command code for the specific task if required after the answering beep.

### THE MEANING OF THE ANSWERING BEEPS

NO.	ANSWERING BEEPS	MEANINGS
1	1 beep	● System is disarmed
2	2 beeps	● System is armed
3	1 beep + 3 beeps	● System is disarmed, but ● Alarm is occurred (due to the 24 hours or the software zones)
4	2 beeps + 3 beeps	● System is armed, and ● Alarm is occurred
5	1 beep + 2 beeps	● System is disarmed, but ● System is in alarm memory, at least one of the protection zones was in alarm
6	5 beeps	● Unsuccessful code entry, try again
7	2 beeps + 5 beeps	● Successful code entry but the function request is rejected due to system arm prohibited

### THE COMMAND CODES FOR REMOTE ACCESS CONTROL

NO.	COMMAND CODES	MEANINGS
A	USER CODE 1 #	● To arm the system if it is disarmed, or ● To disarm the system if it is armed
B	USER CODE 1 * 3 #	● To clear the alarm memory and keep the system in disarmed mode
C	USER CODE 1 * 6 #	● To clear the alarm memory and re-arm the system which is in alarm memory state
D	CLIENT CODE #	● Requesting the system to send a report of its currently registered status to the monitor station or to an auto-pager ● The report will be sent 10 seconds after the command code is successfully entered, 2 beeps will be generated to confirm successful code entry

### REMOTE ARM-DISARM THE SYSTEM BY TELEPHONE

1. Ring the number that the system is connected. In most cases that is the home telephone number of the owner.
2. After the pre-set number of rings (*programmed at location 83*) the system will answer the phone with the answering beep(s) to show its current status.
3. If the owner only wants to check on the STATUS of the alarm system, without making any change, simply hang up after the answering beep is heard.
4. If the owner wants to change the status of the system, now enter the appropriate command code using the telephone keypad. If a mistake is made then press the # key (5 beeps will be heard) and try again. If four incorrect attempts are made to enter the command code, the system will terminate the session and hang up.
5. The command code A can be entered for status change if the answering beep is No.1, 2, 3, or 4; and that the command code B or C can be entered for status change if the answering beep is No.5.

The following is a summary chart that shows the status changes after the command codes are entered:

ANSWERING BEEP NO.	CURRENT STATUS	COMMAND CODE ENTRY	STATUS AFTER COMMAND CODE IS ENTERED
1	System is disarmed	A	System will be armed
2	System is armed	A	System will be disarmed
3	System is disarmed and in alarm condition (due to the 24 hour or the software zones)	A	System will be disarmed, alarm will be reset and changed to alarm memory
4	System is armed and in alarm condition	A	System will be disarmed, alarm will be reset and changed to alarm memory
5	System is disarmed with alarm memory	B	System keeps in disarmed and the alarm memory will be cleared
		C	System will be armed and the alarm memory will be cleared

6. For example, if the system is in disarmed mode, it will be turned ON, **armed**, instantly and two beeps will be heard after the entry of command code A, **user code 1 #**. If the system is in armed mode, it will be turned OFF, **disarmed**, and one beep will be heard to announce that the system is disarmed.

**NOTE:** Selection of HOME or AWAY operation is not available on remote arm-disarm control. The system always arms itself at AWAY mode instantly when the command code is entered.

7. Hang up the telephone immediately to allow the communicator (*if it is enabled, see program Locations 76 and 80*) to ring the monitor station or the paging station as a result of armed or disarmed the system.

In case of ARM PROHIBITED or FORCED TO ARM occurred, the communicator will always ring the monitor station because it is a system problem.

### CALL FOR A STATUS REPORT

The communicator of the alarm system may have been set up to allow the authorized person or the owner to call for a current status report. The procedure is similar to that of remote Arm-Disarm the System stated above.

1. Ring the number that the system is connected with an DTMF telephone.
2. After the pre-set number of rings, the system will answer the phone with the answering beep(s) to show its current status.
3. Enter the **CLIENT CODE** **#**, the command code **D**, using the telephone keypad. If the code entry is correct, two short beeps will be heard to confirm that the request will be done. Hang up the telephone immediately to allow the communicator to send the report. The report will be sent out to the monitor station or to the auto-pager 10 seconds after the confirmation beeps.
4. If a mistake is made in Client Code entry, press the **#** key (*5 beeps will be heard*) and try again. If four incorrect attempts are made, the system will terminate the session and hang up.

## THE AC AND BATTERY POWER

### AC POWER FAILURE AND RESTORATION

The AC power LED indicates the current status, which is ON at AC normal, and it is FLASH at AC failure. The control console gives continuous 1 short beep/30 seconds during the AC power failure period.

- 1) AC power failure lasts for more than 15 minutes, an AC failure report will be sent if the communicator is enable.
- 2) When AC power is restored for 5 minutes, a restoration report will be sent.

### DYNAMIC BATTERY TESTING

The system performs dynamic battery testing on the standby battery by interrupting AC power for 2 minutes and monitoring the battery under loaded condition.

- 1) Dynamic battery testing can be performed any time by manually keying-in the following command codes.

**USER CODE** **\*** **4** **#**

- 2) Dynamic battery testing can be performed daily or weekly automatically with the appropriate command code programmed at Location 86. If the communicator to enabled, a battery status report will be sent on the following testing results:
  - a) The battery is LOW.
  - b) The battery resumes normal but it was LOW.

NO report will be sent, if the battery is normal and it was normal at the last testing.
- 3) The battery's current status is always shown on the BATTERY LED indicator.
- 4) Except the LED light indication, the control console gives continuous 1 short beep/30 seconds after the system announced for battery low until the system retests the battery and considers that the battery has resumed normal again.
- 5) Dynamic battery testing is not accepted in AC power failure condition, or, when the system is in alarm.

### BATTERY LOW INDICATIONS AND AUTO RESET

- 1) The battery low indication begins at 11.0V the battery under loaded condition at dynamic battery testing.
- 2) The battery low indication begins at the battery voltage drops to 11.0V for more than 2 minutes in AC power failure condition. A battery low report will be sent if the communicator is enabled.
- 3) The system will be reset to stop working when the battery voltage drops to 10V in AC power failure condition.



## POWER-UP DELAY

The system can be programmed with or without power-up delay by keying-in the appropriate command code at location 85.

The **AC POWER** and the **BATTERY** lights are flashing alternatively; and the system gives no any function during the power-up delay period.

## THE BACK-UP BATTERY

- 1) The back-up battery for the system should be a 12V, 6.5AH sealed lead-acid battery.
- 2) Replace battery every 3-5 years.
- 3) The standby time is 16 hours at 250mA.
- 4) The maximum battery charge current is 350mA in the system.
- 5) The battery is protected by a built-in 3A resettable fuse in the system.

## GENERAL SPECIFICATION

- Power Source : 16.5V AC, 1.5Amp
- Backup Battery Requirement : 6.5AH, 12V, Rechargeable sealed lead acid
- Temperature Range : 0 Deg C to +65 Deg C
- Standby Current : 110mA
- Protection Zones : 8 Protection zones, end-of-line resistor supervised
- Control Station : Full function control station, 4 in parallel maximum
- G. Weight : 2.5 Kgs  
(One Master Unit & One Control Station packed in Carton)
- Dimensions Master Unit : 265(W) X 270(H) x 78(D) mm  
Control Console : 117(H) X 117(W) X 27(D) mm

## OPENING THE CABINET FOR SERVICE

The Metal Cabinet of the HA-268 is protected by a built-in tamper switch which has been wired to zone 8 at the factory.

Zone 8 is a 24 hour protection zone on default settings. Opening of the Cabinet will trigger the tamper switch to make alarm.

If service is required, such as replacing a back-up battery, checking the connection wires...etc., it is necessary to bypass the tamper switch before opening of the cabinet, and it can be accomplished by one of the following two ways:

- 1) Isolating of the tamper switch can be accomplished by bypassing Zone 8.

Enter your [USER CODE], press the [BYPASS] button, key in the zone number [8] and validate by [#].

[USER CODE] [BYPASS] [8] [#]

- The tamper switch is bypassed, two beeps are generated after the exit delay expired
- The zone 8 LED light is flashing **slow**

- 2) Disable the protection zones by setting system in PROGRAMMING MODE.

Enter the [MASTER CODE] and validate by pressing the [\*] key twice.

[MASTER CODE] [\*] [\*]

- The system is in programming mode, two beeps are generated, the PROGRAM LED light is on.
- The protection zones including zone 8 are disabled while the system is in programming mode.

Now, you can open the Cabinet without making an alarm. Suggest to use a jumper wire (*metal wire*) shorting the tamper switch terminals in order to disable its function in all conditions for those testings and services required the cabinet opened for a period of time. After that, you are allowed to arm-disarm the system, or, to do anything in service without triggering of the tamper switch.

Don't forget to remove the jumper wire that you have put on the tamper switch after service. Before removing the jumper, please make sure that zone 8 is still in bypass or has been set in bypass again after the operational tests in service. Otherwise, the system will give alarm once the jumper wire is removed.