



Fit green link and reset unit to put it into code load mode. Enter the desired code (0-9), '*' to reset, '#' to finish, then remove the green link. The unit will resume normal operation immediately.

An incorrect entry is indicated by the red LED (2) and a descending tone. Correct entry is indicated by the green LED (1) and an ascending tone. The relay is triggered for ~3.4s. Increase the value in the delay statement on line 138 (delay(2000) to increase the access time.