



MINI BLUETOOTH AMPLIFIER

A 1117




Packing List



Installation Instructions

*speakers and audio cable not included.



1 Reset Button

Press to pause or start.
Press twice to enter pairing mode.
Press and hold until LED indicator flashing with 2 beeps to reset the system.

2 LED Indicator

Quick flashing blue: Bluetooth is ready to pair.
Steady blue: Bluetooth is connected.
Slow flashing blue: audio is playing.

Operation

Step 1. Connect the speaker cables as shown in the fig. 1.
Caution: Please make sure you connect with correct polarity (“+” for positive & “-” for negative)

Step 2. Turn on your Bluetooth audio device and make it discoverable, then choose “BT-Amplifier” to connect.

Step 3. Select and play audio files on your Bluetooth device (for example, Spotify or iTunes)

Caution

- 1 Install Controller App**
Please search “BlueSonix” and download the App from Google Play (Android) or Apple Store (iOS). Follow the instructions in the App to change Bluetooth name and password of this amplifier.
- 2** The effective control distance of Bluetooth is 10 meters.
- 3** Streaming music can be interrupted by obstacles between the device and the Bluetooth amplifier, such as a wall, a metal housing, near devices that use the same frequency, etc.
- 4** If you want to connect your Bluetooth amplifier to another Bluetooth device, please turn off the currently connected Bluetooth device.
- 5** We cannot guarantee that this Bluetooth amplifier is 100% compatible with all Bluetooth devices.



Disposal:

The product with this mark indicates that this product shouldn't be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the local recycle service or contact your point of purchase to withdraw the product.

Troubleshooting

Question	Solution
Speaker does not produce sound	Unplug the Bluetooth amplifier for a few minutes and plug it back in. Connect to Bluetooth as described in the manual.
Devices cannot connect to the amplifier	<ol style="list-style-type: none">1 The Bluetooth amplifier is already connected to another Bluetooth device. Disconnect the connected device and try again.2 The Bluetooth device is not connected properly. Connect to the Bluetooth device after turning off the Bluetooth amplifier and turning it on again.3 The device does not support the compatible profiles required by the Bluetooth amplifier.
Signal reception being disturbed	Position the device closer to the Bluetooth amplifier or remove obstacles between the Bluetooth amplifier and the system. Keep in mind that other devices (such as a microwave, Wi-Fi router) may interfere with the signal.

Specifications

Model	A 1117
Frequency Response	30Hz-18kHz
Power Supply	AC 100-240V, 50/60Hz
Input Sensitivity	> -81dBm@0.1% BER
Output Power (Rated)	2x10W Into 8Ω 2x15W Into 4Ω
Bluetooth Version	V5.1
Bluetooth Distance	10m
Dimensions	159.5x54x35.5mm (6.3"x2.1"x1.4")