
Bluetooth Receiver Module BX-501 / BX-701



- ① PWR Power indicator
- ② LINK Bluetooth connectivity indicator
- ③ AF Audio Frequency indicator
- 4 On/Off/Volume control knob

Operation:

- 1. Turn the knob clockwise to switch on the Bluetooth module. Set a mid-range volume level to begin.
- 2. You will hear a tone and the PWR indicator (LED) will light blue. The LINK indicator will also flash blue to indicate that the module is ready to pair with another Bluetooth device.
- 3. When in pairing mode, activate a Bluetooth connection scan on your smartphone or tablet or similar device that will serve as a source of audio. When the search is complete, select a device named "Okayo GPA" from the pairing list. Your device will attempt to connect with the Bluetooth module.
- 4. When the devices have successfully paired, the module will sound a prompt tone again. The LINK indicator will light steady blue.
- 5. You are now ready to stream audio via the Bluetooth connection from your smartphone or tablet. You can adjust the audio volume on your device or using the volume knob on the Bluetooth receiver module.
- 6. The AF indicator will light when an audio signal is streamed from your playback device and received by the Bluetooth module.
- 7. If a phone call is incoming during playback, the audio stream will be interrupted for the user to take the call. When the call is finished, the Bluetooth module will be automatically relinked and audio files will recommence playback from where they were interrupted.
- 8. When a user moves out of range for the Bluetooth connection, the audio stream will be severed until the user returns to a location within range of the module. The range is about 10 metres. However, it depends on what kind of operating system is installed on the smartphone or tablet. Sometimes it will be necessary to manually reconnect to the Bluetooth following the steps above.