

DYNALINK

C 9034A

Super Comfortable Foldable
Wireless Bluetooth Headphones

Operating Instructions



Features

Foldable Design, 10-15m Working Range Distance, Answer phone calls and talk, Up to 15 hours listening time, Adjustable headband, Silicone Headband for extra comfort

Overview

These over ear headphones are not only super comfortable but they also deliver up to 15 hours of listening time. With the added feature of being foldable they are great for travel, commutes to work and the office. The headphones also feature a silicone headband for extra comfort. The 10m working range makes them ideal to wear around the house whilst doing housework or odd jobs. Lastly the over ear design is great for noise isolation.

Box Contents


1. 1x Wireless Bluetooth headphones
2. 1x Charging cable
3. 1x Aux-in cable
4. 1x User manual

Specifications

Bluetooth Version	V5.0
Battery	3.7V 400mah
Sensitivity	97+/-3DB
Impedance	32 ohms+/-10%
Working Distance Range	10 -15m
Working Time	10 - 15hrs
Charge Time	1 - 2hrs
Standby Time	150hrs

Product Diagram

1. Next song/Volume Up
2. Pause/Play/Call/Voice Control
3. Previous song/Volume down
4. Power on/off
5. USB Jack
6. Aux Jack
7. Mic
8. LED



LED Indicator Light Status

Charging Status	Steady red LED. When fully charged, LED indicator light turns off
Power on Status	Blue LED indicator light turns on
Power off Status	LED indicator light turns off
Pairing Status	Blue and Red LED indicator lights rapidly alternating flash
Standby Status	Blue LED indicator light turns on
Connected Status	Blue LED indicator light turns on
Using Status	Bluetooth Mode Blue LED indicator light flashes slowly. AUX-in Mode, the headphone automatically turns off, LED light goes out

Button Description

ON/OFF : ON/OFF Switch

▶||/) : Play / Pause / Phone call (double press)

⏮/V+ : Previous track (press 3s) and volume up

⏭/V- : Next track (press 3s) and volume down

Charging the Headphones

1. Insert the USB cable into a USB port.
2. Connect the cable to the USB port of the headset.
3. The LED indicator will turn red to show the headphone is in charge.
4. The LED indicator will turn off when the battery is fully charged.
5. It takes 2 hours to fully charge the battery.

Button Function Description

1) Pairing Operation:

- a. For the first time pairing: Turn on the Bluetooth headphone, voice prompts "Power on", which will boot into Bluetooth Mode automatically, voice prompts "Bluetooth Mode", LED indicator light rapidly alternating flashes with blue and red colors. Please open the smart device's Bluetooth searching function, and select the device "DYNALINK", no password required, after successful pairing, voice prompts "Connected", LED indicator light stays blue.
- b. Re-pairing: Turn off the attached smart device's Bluetooth function, voice prompts "Disconnected", if it can't search and pair with the last connected smart device within 3 seconds, the headphone will automatically re-enter pairing mode, LED indicator light rapidly alternating flashes with blue and red colors. Open another smart device's Bluetooth searching function, and select the device "DYNALINK", no password required, after successful pairing, voice prompts "Connected", LED indicator light stays blue.
- c. Follow-up pairing: Automatically pair the last connected device in 3 seconds after boot.

2) Answer Call:

Short press ►|| when phone call is coming.

3) Hang up phone calls:

Short press ►|| after calling.

4) Reject Calls:

Long press ►||

5) Redial the last outgoing number:

Double-click ►||

6) Music Play:

Short press ►|| after connected with the smart device.

7) Google Assistant:

Long press ►|| to activate.

Line-in Mode:

When the headphone is on, insert the Aux-in cable, voice prompts "Line-in mode". Then it plays smart device's media automatically.

1. Maximum volume warning voice prompts "du du".
2. Battery indication on IOS.
3. Micro USB as common use charging port.

Note:

1. To avoid hearing damage, limit listening times at high volume.
2. Do not turn up the volume to a level where you do not hear the surrounding sounds.
3. In dangerous situations it is necessary to pay attention or stop temporarily listening.
4. It is not advisable to use the headphones covering both ears while driving; such use could be considered illegal in some countries.
5. For your own safety, avoid distracting yourself by listening to music or phone calls especially in traffic or in other potentially dangerous environments.

C 9034A Foldable Wireless Bluetooth Headphones

Altronic Distributors warrants this product for one year from date of purchase from Altronics or its resellers to the consumer. If this item is part of an installation or another product, please contact the installer or supplier for your warranty.

During the warranty period, we undertake to repair or replace your product at no charge if found to be defective due to a manufacturing fault. The warranty excludes damage by misuse or incorrect installation (i.e. failure to install and operate device according to specifications in the supplied instruction manual), neglect, shipping accident, or no fault found, nor by use in a way or manner not intended by the supplier. For speakers, misuse includes burnt out voice coils.

For repair or service please contact your PLACE OF PURCHASE.

If this item was purchased directly from Altronics please make a warranty claim by:

1. FOR MAIL ORDER CUSTOMERS (includes school and trade orders),

- a) Ringing us on 1300 797 007 and quoting your tax invoice number.
- b) Upon contacting Altronics, we will issue an R.A. (Return Authorisation). As Altronics have a number of service agents throughout Australia, a copy of the R.A. will be emailed, faxed or mailed to you with full instructions of how and where to send the goods. The freight for shipping goods back to Altronics for all repairs is at the customer's expense.
- c) A copy of the R.A. form, (or at the very minimum, the R.A. number) must accompany the goods to effect the repair.
- d) Altronics will pay the return freight to the customer where the warranty claim has been accepted.
- e) Please quote the R.A. number in any correspondence to us.

2. FOR OVER THE COUNTER PURCHASES; to make a warranty claim, please return the goods to us in any of our stores, with a copy of your proof of purchase (tax invoice).

- a) Upon leaving the goods at one of our stores, an R.A. number will be issued to you.
 - b) Once repaired, you will be contacted, advising that the goods are ready to be collected from the store.
- It is at Altronics discretion as to whether the goods will be repaired or replaced (whilst under warranty); and as to whether identical goods will be used to replace the item due to changes of models / products.

Note: Under no circumstances should you attempt to repair the device yourself or via a non-authorised Altronics service centre, as this will invalidate the warranty!

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.